
Checking for leaks is easy but you may not find an intermittent leak only checking one time
Check the numbers here to see if they have increased
Check the location of the line on this dial for movement overnight
REMOVE AFTER
INSTALLATION
GALLONS
5/8" SR®
PD